

A first look at applications and the icoFoam/cavity work procedure

Applications: Solvers and Utilities

- OpenFOAM is first and foremost a *C++ library*, used primarily to create executables, known as *applications*. The applications fall into two categories: *solvers*, that are each designed to solve a specific continuum mechanics problem; and *utilities*, that are designed to perform tasks that involve data manipulation.
- Special applications for pre- and post-processing are included in OpenFOAM. Converters to/from other pre- and post-processors are available.
- OpenFOAM is distributed with a large number of applications, but soon any advanced user will start developing new applications for his/ her special needs. The basic way to do this is to find and copy an application that almost does what is needed, and then to modify it by copy/paste from other applications that has some features that are needed.

We will now have a look at how to use this in practice. NOTE that the output of the commands in the following slides might not be exactly the same in all versions of OpenFOAM, but the general procedures are the same.

The icoFoam/cavity tutorial

- Basic procedure when running a tutorial, in this case `icoFoam/cavity`:

```
cp -r $FOAM_TUTORIALS/incompressible/icoFoam/cavity $FOAM_RUN
run
cd cavity
```

You have copied the `cavity` tutorial and moved to `$FOAM_RUN/cavity`

- The mesh is defined by a dictionary that is read by the `blockMesh` utility

```
blockMesh
```

You have now generated the mesh in OpenFOAM format. Check the output from `blockMesh`!

- Check the mesh by

```
checkMesh
```

You see the mesh size, the geometrical size and some mesh checks (e.g. cell volumes).

- This is a case for the `icoFoam` solver, so run

```
icoFoam >& log&
```

You now ran the simulation in background using the settings in the case, and forwarded the errors and standard output to the `$FOAM_RUN/cavity/log` file, where the Courant numbers and the residuals are shown.

Application parameters

Most OpenFOAM applications take parameters. Use the `-help` flag to get info:

- `blockMesh -help`
(do it and look at the output in the terminal window)

The `[-case dir]` is the most common one, and with that you can specify the path to the case directory if you do not want to move to that case directory.

- `checkMesh -help`
(do it and look at the output in the terminal window)
- `icoFoam -help`
(do it and look at the output in the terminal window)

A graphical view of the icoFoam/cavity tutorial

- We will now have a quick look at the results using paraFoam:


`paraFoam`

Click on 'Last Frame':



Click Apply.

Color by Pressure using `Display/Color by`



Move, rotate and scale the visualization using the mouse

- We will learn how to use paraFoam more further on.
- Exit paraFoam: `File/Exit`
- The results may also be viewed using third-party products:
`foamToEnight` etc., type: `foamTo[TAB]` to see alternatives.
There is also a direct reader for Enight - see the UserGuide.
- For post-processing in Fluent, run:
`foamMeshToFluent`, and `foamDataToFluent` (`controlDict` is used to specify the time step, and a `foamDataToFluentDict` dictionary is required - see the UserGuide).

icoFoam/cavity tutorial - What did we do?

- We will have a look at what we did when running the `cavity` tutorial by looking at the case files.
- First of all it should be noted that `icoFoam` is a *Transient solver for incompressible, laminar flow of Newtonian fluids*
- The case directory originally contains the following sub-directories: `0`, `constant`, and `system`. After our run it also contains the output `0.1`, `0.2`, `0.3`, `0.4`, `0.5`, and `log`
- The `0*` directories contain the values of all the variables at those time steps. The `0` directory is thus the initial condition.
- The `constant` directory contains the mesh and a `transportProperties` dictionary for the kinematic viscosity.
- The `system` directory contains settings for the run, discretization schemes, and solution procedures.
- The `icoFoam` solver reads the files in the case directory and runs the case according to those settings.

icoFoam/cavity tutorial - The constant directory

- The `constant/transportProperties` file is a dictionary for the dimensioned scalar `nu`.
- The `polyMesh` directory originally contains the `blockMeshDict` dictionary for the `blockMesh` mesh generator, and now also the mesh in OpenFOAM format.
- We will now have a quick look at the `blockMeshDict` dictionary in order to understand what mesh we have used.

icoFoam/cavity tutorial - blockMeshDict dictionary

- The blockMeshDict dictionary first of all contains a number of vertices:

```
convertToMeters 0.1;
vertices
(
    (0 0 0)
    (1 0 0)
    (1 1 0)
    (0 1 0)
    (0 0 0.1)
    (1 0 0.1)
    (1 1 0.1)
    (0 1 0.1)
);
```

- There are eight vertices defining a 3D block. OpenFOAM always uses 3D meshes, even if the simulation is 2D.
- `convertToMeters 0.1;` multiplies the coordinates by 0.1.

icoFoam/cavity tutorial - blockMeshDict dictionary

- The blockMeshDict dictionary secondly defines a block and the mesh from the vertices:

```
blocks
(
    hex (0 1 2 3 4 5 6 7) (20 20 1) simpleGrading (1 1 1)
);
```

- hex means that it is a structured hexahedral block.
- (0 1 2 3 4 5 6 7) is the vertices used to define the block. The order of these is important - they should form a right-hand system! See the UserGuide.
- (20 20 1) is the number of mesh *cells* in each direction.
- simpleGrading (1 1 1) is the expansion ratio, in this case equidistant. The numbers are the ratios between the end cells along three edges. See the UserGuide.

icoFoam/cavity tutorial - blockMeshDict dictionary

The blockMeshDict dictionary finally defines three patches:

```
boundary
(
    movingWall
    {
        type wall;
        faces
        (
            (3 7 6 2)
        );
    }
    fixedWalls
    {
        type wall;
        faces
        (
            (0 4 7 3)
            (2 6 5 1)
            (1 5 4 0)
        );
    }
    frontAndBack
    {
        type empty;
        faces
        (
            (0 3 2 1)
            (4 5 6 7)
        );
    }
);
```

icoFoam/cavity tutorial - blockMeshDict dictionary

- Each patch defines a type, a name, and a list of boundary faces
- Let's have a look at the fixedWalls patch:

```
fixedWalls{
    type wall;
    faces
    (
        (0 4 7 3)
        (2 6 5 1)
        (1 5 4 0)
    );}
```

- wall is the type of the boundary.
- fixedWalls is the name of the patch.
- The patch is defined by three sides of the block according to the list, which refers to the vertex numbers. The order of the vertex numbers is such that they are marched clock-wise when looking from inside the block. This is important, and unfortunately checkMesh will not check this.

icoFoam/cavity tutorial - blockMeshDict dictionary

- There are two empty sub-dictionaries in the `icoFoam/cavity` tutorial:

```
edges ();  
mergePatchPairs ();
```

- `edges ();` is used to define shapes of the edges if they are not straight - `polySpline`, `polyLine`, `line`, `simpleSpline`, `arc`. We will use `arc` later on.
- `mergePatchPairs ();` is used to stitch two blocks that are not connected, but share the same physical surface at a patch of each block. This means that both blocks have a patch which is defined with four vertices in the same location as the corresponding patch in the neighbouring block, but the vertices are not the same in both blocks. It should be possible to stitch non-conformal meshes so the number of nodes and the distribution of the nodes do not have to be the same on both sides. This can also be done for two separate meshes, using the `stitchMesh` utility. We will do that later.

icoFoam/cavity tutorial - blockMeshDict dictionary

- To sum up, the blockMeshDict dictionary generates a block with:
x/y/z dimensions 0.1/0.1/0.01
20×20×1 cells
wall fixedWalls patch at three sides
wall movingWall patch at one side
empty frontAndBack patch at two sides
- The type `empty` tells OpenFOAM that it is a 2D case, i.e. the equations will not be solved for in the direction of the `empty` patches. In fact, the discretization will explicitly neglect the third direction, which makes the numerical problem purely 2D.
- Read more about `blockMesh` yourself in the UserGuide.
- You can also convert mesh files from third-party products - see the UserGuide. If you use ICEM, a good procedure is to write a Fluent mesh file (`*.msh`) and convert it with `fluentMeshToFoam` or `fluent3DMeshToFoam`.

icoFoam/cavity tutorial - the mesh

- blockMesh uses the blockMeshDict to generate some files in the constant/polyMesh directory:

```
boundary  faces  neighbour  owner  points
```

- In the following slides we will discuss them...

icoFoam/cavity tutorial - the boundary file

- The boundary file shows the definitions of the patches, for instance:

```
movingWall
{
    type                wall;
    inGroups            1 (wall);
    nFaces              20;
    startFace          760;
}
```

- The faces are numbered, starting with the internal faces, following with the boundary faces. That is why the first patch starts with face 760.
- The `movingWall` patch has 20 faces, and the next patch starts at face 780.
- Each patch can be put `inGroups` for pre- and post-processing purpose. Each patch can thus be in several groups. The `patchGroup` generated by this makes e.g. setting of boundary conditions easier. A patch boundary condition definition takes precedence over a `patchGroup` boundary condition. The `patchGroups` are also listed in `paraFoam`.

icoFoam/cavity tutorial - the points file

- The `points` file shows the positions of all the points in the mesh:

```
882
(
(0 0 0)
(0.005 0 0)
(0.01 0 0)
(0.015 0 0)
...
)
```

- There are 882 points in this case.
- The points have an internal number: 0, 1, 2, ..., 881

icoFoam/cavity tutorial - the faces file

- The `faces` file shows the definitions of the faces in the mesh:

```
1640
(
4 (1 22 463 442)
4 (21 462 463 22)
4 (2 23 464 443)
4 (22 463 464 23)
...
)
```

- There are 1640 faces in the mesh.
- The faces have an internal number: 0, 1, 2, ..., 1639
- The first 759 faces are internal (remember from the boundary file!)
- The numbers in the brackets correspond to the numbers of the points that form each face.

icoFoam/cavity tutorial - the owner file

- The `owner` file defines which cell owns each face:

```
1640
(  
0  
0  
1  
1  
...  
)
```

- There are 1640 faces in the mesh, so each line corresponds to a face.
- face **0** (line zero) is owned by cell **0** (the number on that line)
face **1** (line one) is owned by cell **0** (the number on that line)
face **2** (line two) is owned by cell **1** (the number on that line)
face **3** (line three) is owned by cell **1** (the number on that line)
...
- The face area vector is defined to point out of the owner cell.

icoFoam/cavity tutorial - the neighbour file

- The `neighbour` file defines which cell is the neighbour of the owner of each face:

```
760  
(  
1  
20  
2  
21 ...  
)
```

- There are 760 internal faces in the mesh. The boundary faces only have an owner cell.
- face **0** is owned by cell 0 (as before), and cell **1** is the neighbouring cell
face **1** is owned by cell 0 (as before), and cell **20** is the neighbouring cell
face **2** is owned by cell 1 (as before), and cell **2** is the neighbouring cell
face **3** is owned by cell 1 (as before), and cell **21** is the neighbouring cell
...
- The face area vector is defined to point into the neighbour cell.

icoFoam/cavity tutorial - The system directory

- The `system` directory consists of three set-up files:

```
controlDict  fvSchemes  fvSolution
```

- `controlDict` contains general instructions on how to run the case.
- `fvSchemes` contains instructions on which discretization schemes that should be used for different terms in the equations.
- `fvSolution` contains instructions on how to solve each discretized linear equation system. It also contains instructions for the PISO pressure-velocity coupling.

icoFoam/cavity tutorial - The controlDict dictionary

- The `controlDict` dictionary consists of the following lines:

```
application      icoFoam;
startFrom        startTime;
startTime        0;
stopAt           endTime;
endTime          0.5;
deltaT           0.005;
writeControl     timeStep;
writeInterval    20;
purgeWrite       0;
writeFormat      ascii;
writePrecision   6;
writeCompression off;
timeFormat       general;
timePrecision    6;
runTimeModifiable true;
```

icoFoam/cavity tutorial - The controlDict dictionary

- `application icoFoam;`
Was previously used to tell the GUI `FoamX` in `OpenFOAM-1.4.1` (and earlier) to use the set-up specifications of the `icoFoam` solver.
Is used for the `Allrun` scripts in the `tutorials` directory, but it will not influence the solution as long as you manually start the case with the correct solver.
- The following lines tells `icoFoam` to start at `startTime=0`, and stop at `endTime=0.5`, with a time step `deltaT=0.005`:

```
startFrom      startTime;  
startTime      0;  
stopAt         endTime;  
endTime        0.5;  
deltaT         0.005;
```

icoFoam/cavity tutorial - The controlDict dictionary

- The following lines tells `icoFoam` to write out results in separate directories (`purgeWrite 0;`) every 20 `timeStep`, and that they should be written in uncompressed `ascii` format with `writePrecision 6`. `timeFormat` and `timePrecision` are instructions for the names of the time directories.

```
writeControl      timeStep;  
writeInterval    20;  
purgeWrite       0;  
writeFormat      ascii;  
writePrecision   6;  
writeCompression off;  
timeFormat       general;  
timePrecision    6;
```

I recommend the use of `writeCompression on;` and `writeFormat ascii;`, which does not fill up your hard drive, and you can still open the files with `vim`. For fine dynamic meshes, it is recommended to use the binary format, to avoid deterioration of the mesh.

icoFoam/cavity tutorial - The controlDict dictionary

- `runTimeModifiable true;` allows you to make modifications to the case while it is running.

Specifying a maximum Courant number and varying time steps

- Some solvers, like the `interFoam` solver allows a varying time step, based on a maximum Courant number. Some extra entries should then be added to the `controlDict` dictionary:

```
adjustTimeStep  on;  
maxCo           0.5;  
maxAlphaCo     0.2;  
maxDeltaT      1;
```

- The solver is then told to adjust the time step so that the output still occurs at specific times using:

```
writeControl    adjustableRunTime;  
writeInterval   0.05;
```

icoFoam/cavity tutorial - A dictionary hint

- If you don't know which entries are available for a specific key word in a dictionary, just use a dummy and the solver will list the alternatives, for instance:

```
stopAt          dummy;
```

When running icoFoam you will get the message:

```
dummy is not in enumeration
4
(
endTime
writeNow
noWriteNow
nextWrite
)
```

and you will know the alternatives.

This does not work for all entries for some reason. In some cases, a message is written and a default value is used. Check the log file!

icoFoam/cavity tutorial - More dictionary hints

- You may also use C++ commenting in the dictionaries:

```
// This is my comment
/* My comments, line 1
   My comments, line 2 */
```

- Dictionary expansion mechanism:

- Include another file:

```
#include "boundaryConditions"
```

- Define parameters:

```
velocity1      1;
```

- Use parameters:

```
$velocity1
```

icoFoam/cavity tutorial - The fvSchemes dictionary

- The `fvSchemes` dictionary defines the discretization schemes, in particular the time marching scheme and the convections schemes:

```
ddtSchemes
{
    default          Euler;
}
divSchemes
{
    default          none;
    div(phi,U)      Gauss linear;
}
```

- Here we use the first-order `Euler` implicit temporal discretization, and the second-order `linear` (central-difference) scheme for convection.
- `default none;` means that schemes must be explicitly specified.
- Find the available convection schemes using a 'dummy' dictionary entry.

icoFoam/cavity tutorial - The fvSolution dictionary

- The `fvSolution` dictionary defines the solution procedure.
- The solutions of the p linear equation systems is defined by:

```
p
{
    solver          PCG;
    preconditioner  DIC;
    tolerance       1e-06;
    relTol          0;
}
```

- The p linear equation system is solved using PCG (see later), with the DIC preconditioner (see later).
- The solution is considered converged when the residual has reached the tolerance, or if it has been reduced by `relTol` at each time step.
- `relTol` is here set to zero since we use the PISO algorithm. The PISO algorithm only solves each equation once per time step, and we should thus solve the equations to tolerance `1e-06` at each time step. `relTol 0;` disables `relTol`.

icoFoam/cavity tutorial - The fvSolution dictionary

- The solutions of the U linear equation systems is defined by:

```
U
{
    solver          smoothSolver;
    smoother        symGaussSeidel;
    tolerance       1e-05;
    relTol          0;
}
```

- The U linear equation system is solved using `smoothSolver` (see later), with the `symGaussSeidel` smoother (see later).
- The solution is considered converged when the residual has reached the tolerance `1e-05` for each time step.
- `relTol` is again set to zero since we use the PISO algorithm. `relTol 0;` disables `relTol`.

Main linear solvers

See:

http://www.tfd.chalmers.se/~hani/kurser/OS_CFD_2008/TimBehrens/tibeh-report-fin.pdf

<http://www-users.cs.umn.edu/~saad/books.html>

and descriptions using:

```
emacs $FOAM_SRC/OpenFOAM/matrices/lduMatrix/solvers/*/*.H)
```

- GAMG - Geometric agglomerated algebraic multigrid solver (also named Generalised geometric-algebraic multi-grid in the manual)
- PBiCG - Preconditioned bi-conjugate gradient solver for asymmetric ldu-Matrices using a run-time selectable preconditioner
- PCG - Preconditioned conjugate gradient solver for symmetric lduMatrices using a run-timeselectable preconditioner
- `smoothSolver` - Iterative solver using smoother for symmetric and asymmetric matrices which uses a run-time selected smoother, e.g. Gauss-Seidel.

Preconditioners (1/2)

See:

http://www.tfd.chalmers.se/~hani/kurser/OS_CFD_2008/TimBehrens/tibeh-report-fin.pdf

and descriptions using:

```
emacs $FOAM_SRC/OpenFOAM/matrices/lduMatrix/preconditioners/*/*.H)
```

- `diagonalPreconditioner` - Diagonal preconditioner for both symmetric and asymmetric matrices. This preconditioner actually does not help with faster propagation through the grid, but it is very easy and can be a good first step. Note: The reciprocal of the diagonal is calculated and stored for reuse because on most systems multiplications are faster than divisions.
- `DICPreconditioner` - Simplified diagonal-based incomplete Cholesky preconditioner for symmetric matrices (symmetric equivalent of DILU). The reciprocal of the preconditioned diagonal is calculated and stored.
- `DILUPreconditioner` - Simplified diagonal-based incomplete LU preconditioner for asymmetric matrices. The reciprocal of the preconditioned diagonal is calculated and stored.

Preconditioners (2/2)

- `FDICPreconditioner` - Faster version of the `DICPreconditioner` diagonal-based incomplete Cholesky preconditioner for symmetric matrices (symmetric equivalent of DILU) in which the reciprocal of the preconditioned diagonal and the upper coefficients divided by the diagonal are calculated and stored.
- `GAMGPreconditioner` - Geometric agglomerated algebraic multigrid preconditioner (also named Generalised geometric-algebraic multi-grid in the manual).
- `noPreconditioner` - Null preconditioner for both symmetric and asymmetric matrices.

Smoothers (1/2)

See:

http://www.tfd.chalmers.se/~hani/kurser/OS_CFD_2008/TimBehrens/tibeh-report-fin.pdf

and descriptions using:

```
emacs $FOAM_SRC/OpenFOAM/matrices/lduMatrix/smoothers/*/*.H)
```

- **DIC** - Simplified diagonal-based incomplete Cholesky smoother for symmetric matrices.
- **DICGaussSeidel** - Combined DIC/GaussSeidel smoother for symmetric matrices in which DIC smoothing is followed by GaussSeidel to ensure that any "spikes" created by the DIC sweeps are smoothed-out.
- **DILU** - Simplified diagonal-based incomplete LU smoother for asymmetric matrices. ILU smoothers are good smoothers for linear multigrid methods.
- **DILUGaussSeidel** - Combined DILU/GaussSeidel smoother for asymmetric matrices in which DILU smoothing is followed by GaussSeidel to ensure that any "spikes" created by the DILU sweeps are smoothed-out.

Smoothers (2/2)

- `GaussSeidel` - The GaussSeidel method is a technique used to solve a linear system of equations. The method is an improved version of the Jacobi method. It is defined on matrices with non-zero diagonals, but convergence is only guaranteed if the matrix is either diagonally dominant, or symmetric and positive definite.
- `symGaussSeidel`, `nonBlockingGaussSeidel`, `FDIC`

icoFoam/cavity tutorial - The fvSolution dictionary

- The settings for the PISO algorithm are specified in the PISO entry:

```
PISO
{
    nCorrectors          2;
    nNonOrthogonalCorrectors 0;
    pRefCell             0;
    pRefValue            0;
}
```

- `nCorrectors` is the number of PISO correctors. You can see this in the log file since the p equation is solved twice, and the pressure-velocity coupling is thus done twice.
- `nNonOrthogonalCorrectors` adds corrections for non-orthogonal meshes, which may sometimes influence the solution (see `plateHole` tutorial).
- The pressure is set to `pRefValue 0` in cell number `pRefCell 0`. This is over-ridden if a constant pressure boundary condition is used for the pressure.
- We will have a closer look at the PISO algorithm later.

icoFoam/cavity tutorial - The 0 directory

- The 0 directory contains the dimensions, and the initial and boundary conditions for all primary variables, in this case p and U . U-example:

```
dimensions      [0 1 -1 0 0 0 0];
internalField   uniform (0 0 0);
boundaryField
{
    movingWall
    {
        type      fixedValue;
        value      uniform (1 0 0);
    }
    fixedWalls
    {
        type      fixedValue;
        value      uniform (0 0 0);
    }
    frontAndBack
    {
        type      empty;
    }
}
```

icoFoam/cavity tutorial - The 0 directory

- `dimensions [0 1 -1 0 0 0 0]`; states that the dimension of U is m/s . We will have a further look at this later on.
- `internalField uniform (0 0 0)`; sets U to zero internally.
- The boundary patches `movingWall` and `fixedWalls` are given the type `fixedValue`; value `uniform (1 0 0)`; and `(0 0 0)` respectively, i.e. $U_x = 1m/s$, and $U = 0m/s$ respectively.
- The `frontAndBack` patch is given type `empty`; , indicating that no solution is required in that direction since the case is 2D.
- You should now be able to understand `0/p` also.
- The resulting `0.*` directories are similar but the `internalField` is now a nonuniform `List<vector>` containing the results. Some boundary condition types also give nonuniform `List`. There is also a `phi` file, containing the resulting face fluxes that are needed to give a perfect restart. There is also some time information in `0.*/uniform/time`. The `0.*/uniform` directory is used for uniform information in a parallel simulation.

icoFoam/cavity tutorial - The log file

- If you followed the earlier instructions you should now have a log file. That file contains mainly the Courant numbers and residuals at all time steps:

```
Time = 0.09
```

```
Courant Number mean: 0.220582 max: 0.851424
```

```
smoothSolver: Solving for Ux, Initial residual = 0.000444982,  
Final residual = 6.03872e-06, No Iterations 8
```

```
smoothSolver: Solving for Uy, Initial residual = 0.000969729,  
Final residual = 7.57907e-06, No Iterations 9
```

```
DICPCG: Solving for p, Initial residual = 0.000971271,  
Final residual = 4.7532e-07, No Iterations 26
```

```
time step continuity errors : sum local = 3.92322e-09,  
global = -5.12852e-21, cumulative = -2.64764e-18
```

```
DICPCG: Solving for p, Initial residual = 0.000742827,  
Final residual = 9.70686e-07, No Iterations 25
```

```
time step continuity errors : sum local = 7.98147e-09,  
global = -5.01685e-19, cumulative = -3.14932e-18
```

```
ExecutionTime = 0.05 s ClockTime = 0 s
```

icoFoam/cavity tutorial - The log file

Looking at the `Ux` residuals

- `smoothSolver: Solving for Ux, Initial residual = 0.000444982, Final residual = 6.03872e-06, No Iterations 8`
- We see that we used the `smoothSolver` solver.
- The `Initial residual` is calculated before the linear equation system is solved, and the `Final residual` is calculated afterwards.
- We see that the `Final residual` is less than our tolerance in `fvSolution` (`tolerance 1e-05;`).
- The solver used 8 iterations to reach convergence.

Looking at the rest

- The pressure residuals and continuity errors are reported twice each time step. That is due to `nCorrectors 2;` for the `PISO` entry in `fvSolution`.
- The `ExecutionTime` is the elapsed CPU time, and the `ClockTime` is the elapsed wall clock time for the latest time step (approximate!!!).

icoFoam/cavity tutorial - Plot residuals

- It is of interest to have a graphical representation of the residual development.
- The `foamLog` utility is basically a script using `grep`, `awk` and `sed` to extract values from a log file. See `$WM_PROJECT_DIR/bin/foamLog` for the source code.
- `foamLog` uses a database (`foamLog.db`) to know what to extract. The `foamLog.db` database can be modified if you want to extract any other values that `foamLog` doesn't extract by default. (`find $WM_PROJECT_DIR -iname "*foamLog.db"`, or see the top of the output of `foamLog`, and make your own copy to modify in `$HOME/.OpenFOAM/2.4.x/foamLog.db`, which will be used automatically. Instructions are available in the `foamLog.db` file.)
- `foamLog` is executed on the `cavity` case with log-file `log` by:
`foamLog log`
- A directory `logs` has now been generated, with extracted values in ascii format in two columns. The first column is the `Time`, and the second column is the value at that time.
- Type `foamLog -h` for more information.
- The graphical representation is then given by Matlab, `xmgrace -log y Ux_0 p_0` or `gnuplot: set logscale y, plot "Ux_0", "Uy_0", "p_0"`.
- You can also use the user-contributed `pyFoam` to plot residuals on-the-fly (later).